



HUGH CRANE

(Cleaning Equipment) Ltd

SCREEN WASH/ DE-ICER

CONCENTRATED SCREEN WASH & DE-ICER


An economical screen wash for both summer and winter use. Can be used neat in winter as a liquid de-icer.



SCAN FOR INFO

INSTRUCTIONS

- 1 Summer use dilute 1 part screenwash to 30 parts water.
- 2 Winter use dilute 1 part screenwash to 10 parts water. -5° use a 1 part screenwash to 2 parts water.
- 3 Use neat in a spray bottle as a de-icer.



5L



25L



200L



FLAMMABLE LIQUID AND VAPOUR.

Causes eye irritation. May cause drowsiness or dizziness. Repeated exposure may cause skin dryness and cracking. Keep away from heat/sparks/open flames/hot surfaces – No smoking. Do not get in eyes, on skin or on clothing. Use only outdoors or in a well-ventilated area.

UN1993 FLAMMABLE LIQUID, N.O.S. (contains isopropyl alcohol).



MADE IN
BRITAIN